




ECOSCENT

Premium Scenting Solutions




PRODUCT MANUAL LUNA PRO 8

SAFETY PRECAUTIONS

1. Do not use overloaded power supplies, USB ports, sockets, or use damaged power cords and plugs. If used, it may endanger your safety and may cause fire.
2. Please do not open the inside of the scent delivery system as this may cause damage. If the scent delivery system works in error, please read the user manual carefully, follow the normal procedure or consult after-sales.
3. When the scent machine is working, do not disassemble the scent delivery system or shake the scent delivery system vigorously.
4. Do not put the scent machine or power adapter in water. Do not put water in the fragrance bottle.
5. When the scent delivery system is already filled with fragrance oil or cleaning solution, do not invert, tilt or rotate the scent delivery system to prevent liquid spillage and damage of the scent delivery system and surfaces.

IN THE BOX



Plug



Fixing



Nozzle



Key


PRODUCT INSTRUCTIONS

The EcoScent LUNA Pro 8 features advanced diffusion technology that converts fragrance oil into a fine, dry, mist, releasing fragrance safely and directly into your environment without sprays or aerosols. Its features: the scent diffusion speed is fast, the atomised particle is fine and smooth, the oil consumption is stable and low.

The EcoScent LUNA Pro 8 uses a professional diaphragm pump which can work for 10,000 hours. The EcoScent LUNA Pro 8 has a touch button panel on the LCD screen to control the working time and aroma concentration based on your preference. This is controlled via the Bluetooth app. Leading technology with patented micron atomisation makes the LUNA Pro 8's aroma diffuse and spread quickly providing a long lasting fragrance.

MODEL NO	Luna Pro 8	DIMENSION	249 x 114 x 223mm
OIL CAPACITY	800 ml	N.W.	2.1 kg
COVERAGE AREA	3500 m ³	VOLTAGE	12 V
POWER	12W	NOISE	<40 Dba
OIL CONSUMPTION	3.1ml per hour on 100%	INSTALLATION METHOD	HVAC Free Standing / wall mounted

INSTALLATION INSTRUCTIONS




The scent unit can be floor standing or wall mounted.

- When wall mounting use the fixing screws enclosed and use the sticky hanging plate guide for accuracy.
- Avoid installing at eye level height. The scent system can be floor standing or wall mounted at low level. If installed at height allow 30 cm distance from the ceiling.


1. Open the scent machine by using the key provided in the device lock.
2. Unscrew the atomizing cap and take out the internal bottle.
3. Pour the fragrance into the internal bottle.
4. Screw the bottle onto the atomizer head, then place it back into the machine.
5. Plug in the power cord & turn on the power switch.
6. Set the operation times via the app or using the LCD screen and enjoy the fragrance.

MANUAL OPERATION INSTRUCTIONS

1.The turn on/off interface is shown in the image below, and it takes two seconds to turn on:



2. Display on the main interface of the device: the Current Working Day; Local Time; Working Time Period; Work/Pause Seconds; The Atomization / Fan Icon, WIFI and Bluetooth Connection Status icons. As shown below



3. Set the working time period and frequency: press the "▶" button enter the setting interface, as shown below:



Main interface for setting time period and working frequency

(1)First: select the work day that needs to be set,press the “

(2)Second:select the set time period, press the “

(3)Third:set the working time period and working frequency, press the “

(4)Fourth:after all these setting,press the “

4. Set the local time and Day: press the “

The diagram shows a rectangular display area. At the top, the days of the week are listed: MON, TUE, WED, THU, FRI, SAT, SUN. A small upward-pointing arrow is positioned under 'MON'. A red line points from the text 'Current Day' to the 'MON' label. In the center of the display, the time '09:00' is shown in a large digital font. A red line points from the text 'Local Time' to the '09:00' display.

Time setting interface

Press the “

5. Set the password of the device: press the “

The diagram shows a rectangular display area. Inside, the password '12 34' is entered twice, separated by a space. A red line points from the text '1.Input password' to the first '12 34'. Another red line points from the text '2.Enter the password again to confirm' to the second '12 34'. Below the second password, there are two lines of smaller text: '4.Adjust End Time' and '5.Adjust pause seconds', both preceded by a small right-pointing arrow.

Password setting interface

(1)Enter the four-digit password for the first time, press the “

(2)Enter the four-digit password for the second time, press the “

- 6. Turn on/off:** Long press the “ENT” button until you hear a “beep”, then you can turn on/off the machine;
- 7. Turn on/off fan:** Long press the “BACK” button to turn on /off the fan, and observe the status of the fan icon;
- 8. Reset the machine:** Press the “BACK” + “▶” buttons at the same time until you hear the five beeps of “Didi Didi ” then release the button, and the device starts reset.
- 9. After the device has no button operation for 10 seconds, the display screen will be turned off; Press the button again to wake up the screen backlight.**

Fragrance oil level percentage detection :

The machine has an oil detection sensor that can detect the fragrance oil level state. (Note:Only detect five states such as 100%, 70%, 40%, 10%, and 0%) Refer to Figure 1 The fragrance oil percentage state can be viewed in the APP, as shown in the picture below:(Refer to Figure 2 and Figure 3).




Figure 2




Figure 1





Figure 3

CONNECTING ECOSCENT UNIT TO AROMALINK APP

1. On the App Store, Google Play, or Android App Store search and download the AromaLink app.



2. Open the AromaLink App, you'll see a Bluetooth button. Ensuring your unit is switched ON, click on the 'Bluetooth' button, the app will then search for nearby units. The device name will start with 'Smart.A5WIFI...' on the app select the device name and enter the initial password which is '1234' to connect your scent machine to your phone.




Figure 4




Figure 5




Figure 6




Figure 7

CONTROL INTERFACE

Your control interface should look like the image below:




Figure 8




Figure9

3.View the working status and control the machine:

On the APP, you can check working time and pause time of the device, change the settings and turn on/off the device.

4.Work time Setting

Click "Set up" on the main interface to set working period, support to set five working periods in each day. After setting, please click "Save" to finish the setting. (Refer to Figure 8 and Figure 9).

5. Click “Set up” on the main interface to set the working frequency(Refer to Figures 10 and 11).




Figure 10




Figure 11

6. Rename device :

In order to manage multiple devices, the Bluetooth name of each device can be modified. For example, we can modify the device which put in the meeting room: “Meeting Room 01”.

Modify method: Press the device name “Smart.A1” in the app (Refer to Figure 12), then enter the name modification interface, after you rename the device, click “OK” to confirm the setting. (Refer to Figure 13).




Figure 12




Figure 13

SETTING THE FRAGRANCE CONCENTRATION

The scent system works from 5 to 300 seconds at a time and can be paused from 5 to 300 seconds per your requirements. The longer the pause, the weaker the fragrance. Please follow the guidelines below to setting your desired fragrance concentration. You can set up to 5 different programs.

CONCENTRATION %	WORK	PAUSE
100%	900s	15s
75%	675s	225s
50%	450s	360s
40%	360s	450s
25%	225s	675s
5%	15s	900s

SCENT MACHINE MAINTENANCE

For scent delivery system maintenance advice please refer to our "Clean-Me Guide". Clean with a EcoScent cleaning solution every 2 months or if changing the fragrance. Do not use water in the scent system. Do not tilt the scent system. Please ensure the fragrance oil is replenished regularly.

TROUBLESHOOTING


No scents	1. Check whether the device's battery or powered on or not. 2. Check whether the pump is working or not and whether the nozzle is blocked or not. 3. Check whether the essential oil in the bottle is ran out or not and whether the pipe falls off or not.
Oil leakage	1. Oil leakage inside the machine: Check whether the essential oil bottle is tightened or not. 2. Oil leakage from the mist outlet: Check whether there are obstacle in the mist outlet hole.
Unusual noise	1. Check pump whether fall out , and re-install the air pump. 2. Check whether the mist outlet is blocked by obstacle. 3. Check the pump whether is low airflow and low pressure.

HVAC Installation

- Connect the flexi-hose to the top of the unit.
- Connect the power supply and turn on the side switch to set the time and timer program as detailed earlier in the instructions. Then turn off to complete install.
- Connect the flexi-hose to the air supply outlet of HVAC System. The flexi-hose disperses the scent along with the cold/warm air flow output. A small hole should be drilled into the duct and secured with a stud fitting (HVAC kits are supplied at additional cost).


When completing a self install scent delivery system via HVAC you should check the following points:

1. The flexi-hose should always be pointing upwards.
2. It is recommended that the flexi-hose is trimmed and kept to the minimum length possible with no tangles or loops.
3. The machine should always be kept upright.
4. The flexi-hose should remain secure at both ends.



Scent System Atomiser Core Replacement Guide

A spare Atomiser Core and clear tube are supplied in the box when the Scent Machine is provided to you.




1. Locate the Atomiser Core

Turn off the scent machine. The Atomiser Core is positioned in the top section of the scent machine and is connected to the clear tube that draws fragrance from the bottle.



2. Remove the existing Atomiser Core

Gently pull the Atomiser Core downward to release it from the device. If it is firmly in place, use pliers carefully to assist removal. A small amount of fragrance or cleaning solution may be present, so please protect clothing, skin and surrounding surfaces from possible spills.




3. Install the new Atomiser Core

Insert the replacement Atomiser Core into the unit and reconnect the clear tube, ensuring it is fully and securely seated. Dispose of the old part.



4. Check the installation

Confirm the Atomiser Core is firmly in place and the tube is correctly attached before switching the scent machine back on.



All Done!

Your scent system is now ready to use. Sit back and enjoy your chosen fragrance. If for any reason your scent system is not performing well please reach out to us at ecoscent@ecoscent.co.uk or WhatsApp +44 7361 534520

Care Tips:

Clean any spills immediately to prevent staining or slipping. Fragrance and cleaning solution can spill during replacement. Protect clothing, skin and nearby surfaces, and clean any spills immediately to avoid staining or slipping.

CLEAN ME GUIDE

It is important to regularly clean your scent delivery system with our EcoScent cleaning solution every couple of months to ensure the system runs smoothly and to prevent unnecessary internal damage.

STEP ONE



To clean the scent delivery system, ensure that fragrance oil bottle is empty then half fill with cleaning solution. Turn on the scent system to run as normal for 5-10 minutes.

STEP TWO



Turn off the power, pour out any residual cleaning solution and retain for future use.

STEP THREE



If the scent system is in constant use, the cleaning operation above should be carried out every 2-3 months to ensure ultimate efficiency of the atomised scent delivery technology.

If the equipment is not being used for a long period of time it is recommended that the fragrance oil bottle is emptied and the fragrance oil stored in a dry, dark, secure location. The scent system should then be cleaned with the cleaning solution as mentioned above. Please refer to User Manual for further information.

* Failure to clean the machinery will affect the warranty*

